




Parts List

EAX-300



Item	Order Part #	Description	List Price
1	105428-1	Cover, Gray	\$103
	105428-2	Cover, black	\$91
2	PP-5572	Cover Lock, Nut & 2 Keys	\$19
3	MS-1039S	Mag Switch (surface mount) (see STEP 8)	\$96
4	PP-5567	9 Volt Battery	\$14
5	102606	Battery Retainer	\$4
6	100783	Cylinder Hex Nut	\$10
7	102655	Cam Assembly Kit	\$47
8	102627-15	8-32 Truss Head Screw	\$3
9	105828-1	S & R Circuit Board Kit, Standard	\$247
	105837-1	S & R Circuit Board Kit, Weatherized	\$410
10	102789-1	Screw, SMS, #4 x 1-1/4" PFH	\$2
11	102715	Backplate	\$15
12	102665	Magnet Kit	\$12
13	102607	Magnet Locator	\$3
14	102633	Hardware Kit (includes keystone parts)(not shown)	\$33